

(636) 745-7757 Fax: (636) 745-2874

P.O. Box 110 Foristell, Missouri 63348 10 Cooperative Way Wright City, MO 63390 www.mittlerbros.com

400-100 Chip Tray

Installation Instructions



Pre- 2010 Chip Tray Mounting Hole Location Drawing 400-007- Shown On Back Page

- 1. Attach Drawing To Adapter Plate -
- 2. Center Punch Both Mounting Hole Locations
- 3. Drill And Tap 1/4-20 X 1/2" Deep



Anchor Bolts

